

Remote Key		Customer Code : 0x0080	
Key Name	Data Code	Function Description	Activity
POWER	0x03	Software Power ON/OFF	
INPUT	0x01	Rotates through the display video inputs: HDMI1, HDMI2, PC, VGA, YPbPr, S-Video, CVBS	
MENU	0x1E	Enter OSD Menu	
HOME	0x1D	Change source to PC	
RESIZE	0x29	Performs the Aspect Ratio Advance command	
PIP ON/OFF	0x24	Switch the PIP/POP and OFF	OFF --> PIP --> POP --> PBP(aspect) --> PBP(full) --> OFF
PIP INPUT	0x25	Select the input source of PIP	
PIP SWAP	0x26	Change the PIP/MAIN.	
PIP POSITION	0x27	Cycles through PIP window placement options	Able to position in any of four corners of display
PIP AUDIO	0x28	Turns on/off PIP audio mixing	
BACK	0x1C		IR control shall be set to "Normal" if the "Exit" button is pushed more than 5 sec.
UP	0x15		
DOWN	0x14		
OK	0x23		
PLUS	0x22		
MINUS	0x21		
INFO	0x1F	Information (passthrough for PC)	
BRIGHTNESS	0x19	Enables brightness adjust – slider bar controlled by left and right < >	
CONTRAST	0x20	Enables contrast adjust – slider bar controlled by left and right < >	
MUTE	0x1B	Mute On/Off	
VOL UP	0x17	audio volume up	
VOL DOWN	0x16	audio volume down	

