

- 
- A**
- adjusting the image 17
  - adjusting the projector
    - raise the projector 21
  - advance menu
    - auto shutdown time 33
    - ceiling projection 33
    - display startup screen 34
    - inhibit screen saver 33
    - rear projection 33
    - reset 34
  - advanced menu
    - advance menu 33
  - Apple-Macintosh
    - compatibility 9
  - audio
    - connecting 15
  - audio menu 28
    - balance 28
    - bass 28
    - fade 29
    - mute 29
    - treble 28
    - volume 28
  - audio/visual
    - connecting 17
  - auto image 30
  - auto shut down time
    - advance menu 33
  - auto source
    - controls menu 32
- B**
- balance
    - audio 28
  - bass
    - audio 28
  - Batteries
    - in the remote control 39
  - brightness 27
- C**
- Ceiling project 33
  - Cleaning the filter 40
  - Cleaning the lens 37
  - color 27
  - color temperature 27
  - compatibility
    - Apple-Macintosh 9
    - IBM-Compatible 9
  - computer resolution
    - image menu 35
  - connecting
    - audio 15
    - audio/visual 17
    - cables 15
    - CableWizard3 15
    - computer 14
    - M1-DA cable 15
    - mouse 15
    - PS/2 15
    - speakers 15
    - s-video 16
    - USB 15
    - video player 16
  - controls menu
    - auto source 32
    - default source 32
    - display messages 32
    - standby time 32
- D**
- default source
    - controls menu 32
  - display menu
    - brightness 26, 27
    - color 27
    - color temperature 27
    - keystone + - 26
    - screen color 27
  - display messages
    - controls menu 32
  - display startup screen
    - advance menu 34

---

## **F**

- fade
  - audio 29
- FCC Warning 2
- focus
  - adjusting 19

## **G**

- Guardian Cable Lock System 40

## **H**

- horizontal position 31

## **I**

- IBM-Compatible
  - compatibility 9
- image adjustment
  - basic 19
- image menu 29
  - auto image 30
  - horizontal position 31
  - image position 30
  - manual sync 31
  - manual tracking 31
  - overscan 30
  - resize 29
  - vertical position 31
  - video standard 30
  - zoom 32
- image position 30
- Image resolution 9
- inhibit screen saver
  - advance menu 33

## **K**

- keypad
  - using 23
- keystone + - 27

## **L**

- Lamp
  - replacement lamp 45
- lamp hours used
  - status menu 35
- language menu 34
- laser pointer
  - using 20
- LED's
  - arrow 23
- lens
  - cleaning 37

## **M**

- maintenance 37
- manual sync 31
- manual tracking 31
- menus
  - projector 23
- mouse
  - connecting 15
  - controlling with the remote 20
- mute
  - audio menu 29

## **O**

- On Screen Menus
  - using 25
- Operating temperatures 45
- Optional accessories 47
- overscan 30

## **P**

- Portable and laptop activation chart 46
- positioning the projector 13
- Power cords 46
- Power requirements 45
- power up sequence 17
- Projection lamp
  - replacing 37
- PS/2 mouse
  - connecting 15

---

## R

- Rear project 33
- rear projection
  - advance menu 33
- remote
  - arrow keys 24
  - auto 24
  - freeze 25
  - magnify/pan 25
  - PC1/PC2 25
  - PIP (picture in picture) 24
  - using the LaserPro II 24
  - Video1/Video2 25
- remote control
  - using 20
- remote zoom 24
- replacing the projection lamp 37
- reset
  - advance menu 34
- resize
  - image 29

## S

- safety guidelines vii
- screen color 27
- security lock
  - Guardian Cable Lock System 40
- SimulScan
  - using 53
- software version
  - status menu 35
- source
  - status menu 35
- speakers
  - connecting 15
  - status menu 35
- Specifications 45
- standby
  - adjusting 25
- standby time
  - controls menu 32
- status menu 34

computer resolution 35

lamp hours used 35

software version 35

source 35

speakers 35

s-video

connecting 16

## T

- technical support
  - before you call, information you need 44
  - in Europe 11
  - in Singapore 11
  - in USA 11
- tint 27
- treble
  - audio 28
- troubleshooting 41
- turning the projector off 18

## V

- vertical position 31
- VESA cable
  - connecting 16
- Video mirroring 52
- video player
  - connecting 16
- video standard
  - image menu 30
- video standards
  - broadcast 17
- viewing area
  - adjusting 19
- viewing on monitor 16
- volume
  - audio 28

## W

warranty 59

## Z

zoom 32