
TABLE OF CONTENTS

Safety Instructions	7
Introduction	9
Image Resolution	9
Compatibility	9
Unpacking the Projector	9
Usage Guidelines	11
If You Need Assistance	11
Warranty	11
Setting up the projector	13
Connecting a Computer	14
Connecting a Video Player	16
Powering on the Projector and Adjusting the Image	17
Turning Off the Projector	18
Using The Projector	19
Basic Image Adjustment	19
Adjusting the Projector	21
Using the Keypad and Remote Buttons to navigate	22
Using the Projector Keypad	23
Using the On-Screen Menus	26
Display Menu	26
Audio Menu	28
Image Menu	29
Control Menu	32
Advanced Menu	33
Language Menu	34
Status Menu	35
Maintenance & Troubleshooting	37
Cleaning the Lens	37
Replacing the Projection Lamp	37
Cleaning the Fan Intake Filter	40
Using the Security Lock	41
Troubleshooting	41

Appendix	45
Specifications	45
Accessories	46
Optional Accessories	47
Portable and Laptop Activation Chart	48
Using Video Mirroring with a PowerBook Computer	52
Projected Image Size	53
LIMITED WARRANTY	59